

Prolonged sprayer use through regular and easy cleansing

Clean up Sprayer Liquid – Cleansing Liquid

Our Cleansing Liquid is the optimal accessory for the Easy Multiple Sprayer. Routine application will increase the lifespan of the sprayer.



The mild cleansing solution with long-term effect ensures a long lifespan for the sprayer.

The set contains 12 x 2ml ampoules.

Tip: the cleansing solution is perfect for cleaning your smart phone and tablet display.

Cleansing Liquid:

The mild cleansing solution developed especially for the Easy Multiple Sprayer cleans the pump sprayer and the riser tube from all residues from the previously used ampoule. Thanks to the modern cleansing technology, any deposits and blockages are thoroughly removed and the Easy Multiple Sprayer is then ready for reuse. The fluid of the subsequent ampoule is also protected from microbiological impurities.

Application:

Insert the cleansing ampoule into the sprayer and spray the complete contents into a washbasin or sink. Then remove the ampoule and keep on spraying until all the remaining liquid is sprayed out of the riser tube and no more spray mist comes out. This prevents any interaction with the subsequent application ampoules.

Please note:

- Following of skin contact: in general, the liquid does not irritate skin.
- Following unintentional ingestion: rinse out mouth and drink plenty of water.
 - Following eye contact: rinse eyes for several minutes under running water with the eyes open.
 - With persistent ailment/symptoms: consult a doctor.

Advantages:

- The pump sprayer and the riser tube are cleansed thoroughly of the residues from the ampoule used previously.
- Significant increase in the sprayer application frequency for a long product lifespan.
- Simple and practical application.

Important information



Please note:

Filling:

Check the filling of your ampoules for materials compatibility with the Easy Multiple Sprayer (HDPE/ silicone) and the Easy Daily Box (HDPE/LDPE). We are happy to answer any questions about this issue.

Leakage:

Failure to assemble the sprayer correctly or a defect leads to a danger of leakage. To prevent leaks, do not use the sprayer in the situations described above.

Downloads:

The safety data sheet for the Cleansing Liquid can be found in the download area of our website: www.lutz-packaging.de/en/download



Caution:

Danger of injury:

Sharp-edged broken parts and glass particles from ampoules can cause cuts.

- Take care when handling the ampoules.
- Break the ampoules carefully to avoid cuts and liquid spillage.
- Use only the Easy Daily Box or the Easy Multiple Sprayer to open the ampoules.

Danger of chemical burns:

Aggressive and/or irritating liquids can cause chemical burns if they come into contact with the skin or eyes.

- Never swallow the liquid contents of the ampoules unless they are expressly suitable for oral use.
- Following unintentional ingestion: rinse out mouth and drink plenty of water.
- Following eye contact: rinse eyes for several minutes under running water with the eyes open.
- With persistent ailment/symptoms: consult a doctor.

Lutz Packaging GmbH
Am Stammholz 11 | 97877 Wertheim | Germany
info@lutz-packaging.de

www.lutz-packaging.de/en

AMPOULES
VIALS PHARMA
COSMETICS
ACCESSORIES PACKAGING



A passion for quality

Product news

Innovative accessories



The perfect accessory and practical supplement

Multifunctional application for a great spraying experience

Easy Multiple Sprayer

This highly versatile and practical companion with an integrated ampoule breaker is ideally suited for use with a range of liquids.



The sprayer can be used to spray cosmetic products such as moisturising liquids, make-up fixatives, fluid aromas (aromatherapy), vitamin preparations for the food supplements sector and liquids for medical use. The only requirement is fluid viscosity.

MOQ: 240 pcs.

4 colours, 3 pump sprayers = 12 applications.
Design your own sprayer!



Advantages:

- Integrated ampoule breaker for practical use and the safe opening of glass ampoules, especially when travelling.
- The sprayer has been designed for 2 ml form B ampoules.
- Easy-to-hold and lightweight design.
- Uniform application per spray jet.
- The perfect companion for any journey. The ampoule is sealed tightly, the sprayer fits in any handbag.
- Can be branded with your logo.
- Available in four attractive colours: white, black, grey and bordeaux.

Application



Step 1: Hold the ampoule vertically and tap its head gently with your middle finger to ensure that the liquid flows completely into the body of the ampoule and the ampoule opens cleanly. Then unscrew the pump sprayer at the collar and twist it off the container.

Step 2: Hold the pump sprayer by the collar and apply gentle pressure to pull the rubber grommet from the collar. Should the pump hose become detached, simply reinsert it into the designated opening.

Step 3: Insert the ampoule vertically from below into the integrated ampoule breaker until it clicks. Then press the ampoule gently in any direction to break it.



Step 4: Allow the broken head of the ampoule to fall out of the side of the opening.

Step 5: Slide the open ampoule vertically into the rubber grommet. Then insert the rubber grommet with the ampoule into the pump sprayer as far as it will go.


Step 6: Screw the spray device with the inserted ampoule onto the spray bottle.

Step 7: The Easy Multiple Sprayer is ready for use.

You like everything tidy? So do we!

Easy Daily Box

The practical and elegant ampoule box with integrated ampoule breaker guarantees optimal storage of ampoules and is the perfect companion for every trip.



The ampoule box protects the precious ampoules from breakage and delicate formulas from UV light. Whether in a domestic cosmetics cupboard or a travelling beauty case, the Easy Daily Box permits storage of a total of 9 ampoules (8 + 1x spare ampoule) in a sorted and above all safe manner.

MOQ: 240 pcs.

Storage compartment for both the ampoule and the Cleansing Liquid

Application:

Step 1: Hold the ampoule vertically and tap its head gently with your middle finger to ensure that the liquid flows completely into the body of the ampoule and the ampoule opens cleanly.

Step 2: Insert the ampoule vertically from below into the integrated ampoule breaker of the closed box until it clicks.

Step 3: Gently press the ampoule in any direction to break it.

Step 4: Allow the broken head of the ampoule to fall out of the side of the opening.

Step 5: Remove the ampoule and insert it into a suitable spraying device, for example in the Easy Multiple Sprayer.

PLEASE NOTE: The head of the ampoule has sharp edges!



Advantages:

- Integrated ampoule breaker for practical use and the safe opening of glass ampoules, especially when travelling.
- Sorted storage and safe transport of the precious ampoules, ideal for travelling.
- Handy size, light weight, perfect for any handbag.
- Can be branded with your logo.
- Available in four attractive colours: white, black, grey and bordeaux.